


Mount the servo such that air circulation around the servo is not impeded.



Standard And High-Torque Servo Dimensions